

	1	2	3	4	5	6	7	8
1	z	space	.		right alt		vol +	
2	x	f1	?		play pause	shift	vol -	
3		f4	2		left alt	1	mute	search
4	esc	f6	4			email	ctrl	
5	c	f2	\					web
6	v	f3	1	windows key				
7	backspace	pause	ins					
8	f12	q	j	scr l lock	end	pg up	pg dwn	down
9	f8	s	(-)	u	[8	h	n
10	f9	d	(=)	i]	9	(')	m
11	f10	f	5	o	\	0	\	(,)
12	mouse menu	w	k	numlock	home	4	1	right
13		e	l	/	up	5	2	0
14		r	;	*	9	6	3	.
15	f11	tab	6		home	del	up	left
16	return	f5	3			shift	clac	
17		t	backspace	(-)	(+)		down	caps lock
18	f7	a	`	y	p	7	g	b

White denotes the right side of the keyboard

Grey denotes the left side of the keyboard